

# TA-5111 TEMPLATE

USE TEMPLATE SUPPLIED WITH LOCK FOR ONSITE INSTALLATION

- A - INSTALL TWO M5X15 SCREWS IN SLOTTED HOLES FOR ADJUSTMENT.
- B - DRILL AND TAP ON SITE FOR 8 X 10-24 OR USE SUPPLIED WOOD SCREWS. REINFORCEMENT IS REQUIRED IN STEEL FRAMES.
- C - DRILL  $\frac{9}{16}$ " HOLE FOR WIRING.

DATE: MAY 8, 2010	DRAWN BY: JK
REV#: 0	SCALE: DO NOT SCALE
PROJECT:	
OPENING:	

